




ROTARY BURRS SPARTUS®



CYLINDER ROTARY BURR



➤ STANDARD ➤ HIGH PERFORMANCE




CODE	D1	L2	D2	L1
➤ 040-06-060HP	6	16	6	50
➤ 040-06-080	8	19	6	63
➤ 040-06-080HP	8	20	6	65
➤ 040-06-100HP	10	20	6	65
➤ 040-06-127	12,7	25	6	69
➤ 040-06-127HP	12,7	25	6	70
➤ 040-06-160	16	25	6	69



CYLINDER ROTARY BURR (WITH END CUT)



➤ STANDARD ➤ HIGH PERFORMANCE




CODE	D1	L2	D2	L1
➤ 041-06-060HP	6	16	6	63
➤ 041-06-080	8	19	6	63
➤ 041-06-080HP	8	20	6	65
➤ 041-06-100HP	10	20	6	65
➤ 041-06-127	12,7	25	6	69
➤ 041-06-127HP	12,7	25	6	70
➤ 041-06-160	16	25	6	69



BALL NOSE CYLINDER ROTARY BURR



➤ STANDARD ➤ HIGH PERFORMANCE




CODE	D1	L2	D2	L1
➤ 042-06-060HP	6	16	6	50
➤ 042-06-080	8	19	6	63
➤ 042-06-080HP	8	20	6	65
➤ 042-06-100HP	10	20	6	65
➤ 042-06-127	12,7	25	6	69
➤ 042-06-127HP	12,7	25	6	70
➤ 042-06-160	16	25	6	69

BALL ROTARY BURR



 STANDARD
  HIGH PERFORMANCE




CODE	D1	L2	D2	L1
 043-06-060HP	6	5	6	50
 043-06-080	8	6,4	6	50
 043-06-080HP	8	7	6	53
 043-06-100HP	10	9	6	54
 043-06-127	12,7	11	6	55
 043-06-127HP	12,7	10	6	58
 043-06-160	16	11	6	62

OVAL ROTARY BURR



 STANDARD
  HIGH PERFORMANCE




CODE	D1	L2	D2	L1
 044-06-095	9,5	16	6	60
 044-06-127	12,7	22	6	66
 044-06-127HP	12,7	22	6	66
 044-06-160	16	25	6	69

NOSE TREE ROTARY BURR BALL



 STANDARD
  HIGH PERFORMANCE




CODE	D1	L2	D2	L1
 045-06-060HP	6	16	6	50
 045-06-080HP	8	20	6	65
 045-06-095	9,5	19	6	63
 045-06-100HP	10	20	6	65
 045-06-127	12,7	25	6	69
 045-06-127HP	12,7	25	6	70
 045-06-160	16	25	6	69

➤ TREE ROTARY BURR



➤ STANDARD ➤ HIGH PERFORMANCE




CODE	D1	L2	D2	L1
➤ 046-06-080	8	16	6	63
➤ 046-06-127	12,7	25	6	69
➤ 046-06-127HP	12,7	25	6	70
➤ 046-08-127	12,7	25	8	69
➤ 046-06-160	16	25	6	69

➤ FLAME ROTARY BURR



➤ STANDARD ➤ HIGH PERFORMANCE




CODE	D1	L2	D2	L1
➤ 047-06-080	8	19	6	63
➤ 047-06-080HP	8	18	6	50
➤ 047-06-100HP	10	25	6	65
➤ 047-06-127	12,7	32	8	76
➤ 047-06-127HP	12,7	32	6	76
➤ 047-06-160	16	36	6	80

➤ CONE 60° ROTARY BURR



➤ STANDARD




CODE	D1	L2	D2	L1
➤ 048-06-095	9,5	8	6	55
➤ 048-06-127	12,7	11	6	58
➤ 048-06-160	16	14	6	61

➤ CONE 90° ROTARY BURR



➤ STANDARD




CODE	D1	L2	D2	L1
➤ 049-06-095	9,5	4,7	6	52
➤ 049-06-127	12,7	6,3	6	54
➤ 049-06-160	16	8	6	57

BALL NOSE CONE ROTARY BURR



 **STANDARD**
 **HIGH PERFORMANCE**




CODE	D1	L2	D2	L1
 050-06-060HP	6	16	6	50
 050-06-080	8	22	6	69
 050-06-080HP	8	20	6	45
 050-06-100HP	10	25	6	50
 050-06-127	12,7	27	6	74
 050-06-127HP	12,7	32	6	65
 050-06-160	16	30	6	77

CONE ROTARY BURR



 **STANDARD**
 **HIGH PERFORMANCE**




CODE	D1	L2	D2	L1
 051-06-060HP	6	18	6	50
 051-06-095	9,5	16	6	63
 051-06-100HP	10	20	6	65
 051-06-127	12,7	22	6	69
 051-06-127HP	12,7	25	6	70
 051-08-127	12,7	22	8	69
 051-06-160	16	25	6	73

INVERTED CONE ROTARY BURR



 **STANDARD**



CODE	D1	L2	D2	L1
 052-06-095	9,5	9,5	6	53
 052-06-127	12,7	12,7	6	57
 052-06-160	16	19	6	63