




CE



Circle

A line drawing of a toolbox. Inside the toolbox, there is a wrench on the left, two long rods or pipes in the center, a T-square at the bottom left, and three different types of drill bits on the right.

Central connector



SPARTUS®
SP120H / SP120M
EWS® // LINCOLN®
EX100 / EX100M / EX100M-3 // T100

CODE	REF. NO.	DESCRIPTION
01252/LT-SP1		SP120H Hand torch, 6m (connection SPARTUS®) ¹⁾
01252/LT-SP2		SP120H Hand torch, 6m (central connector SPARTUS®) ²⁾
01252/LT	W0400052	SP120H Hand torch, 6m (central connector)
01352/LT	W0400037	SP120H Hand torch, 12m (central connector)
01452	W0400034	SP120M Machine torch, 6m (central connector)
01552	W0400035	SP120M Machine torch, 12m (central connector)

... other connections see catalog page 4.05

NO.	CODE	REF. NO.	[H] [M]	DESCRIPTION
1	01201/KIT		•	Hand torch head with handgrip
2	01201		•	Hand torch head
2a	02000.60		• •	O-ring (20pcs/pck)
2b	60085		• •	Front insulator
3	09706		•	Handgrip with microswitch
3a	07301.20		•	Switch
4	01400	W0300143	•	Machine torch head
5	03310	W0300144	•	Machine handle
6	06004	W0300122	• •	Diffusor
7	52540	W0300123	• •	Electrode
8	60020	W0300124	• •	Swirl ring
9	51140/S		• •	Tip fi 1.1 Long Life
	51141/S	W0300174	• •	Tip fi 1.35 Long Life
	51142/S	W0300175	• •	Tip fi 1.6 Long Life
	51144.24	W0300128	•	Gouging tip fi 2.4
10	60328	W0300129	•	Retaining cap
11	51910	W0300130	•	Spacer spring (10pcs/pck)
12	60370	W0300131	•	Double pointed spacer
13	60371	W0300177	•	Crown spacer
14	60373	W0300132	•	Gouging spacer
15	60348	W0300138	• •	Contact retaining cap
	60348/V		• •	Contact retaining cap Max Life
16	51952	W0300244	•	Spring holder protection nut
17	51911	W0300245	•	Spacer spring
18	51953		•	Gouging spacer
19	51950	W0300180	•	Spacer for contact cutting, hand
20	51959	W0300184	• •	Locking nut
21	06005		•	Diffusor
22	52549	W0300133	•	Extended electrode
23	51148	W0300134	•	Extended tip max 50A
24	51957	W0300182	•	Shield cap hand max 50A
25	51148.13	W0300178	•	Extended tip fi 1.35 90A
	51148.16	W0300179	•	Extended tip fi 1.6 120A
26	51958	W0300183	•	Shield cap hand
27	51951	W0300181	•	Shield cap machine
28	60369	W0300142	• •	Extractor for swirl ring
29	60368	W0300119	• •	Wrench for electrode
	04241	W0300140	•	Cable, 6m, 1/8" - hand torch
	04251	W0300141	•	Cable 12m, 1/8" - hand torch
	04321	W0300189	•	Cable, 6m, 1/8" - machine torch
	04331		•	Cable, 12m, 1/8" - machine torch
	51851		•	Circle cutting attachment

[H] - parts apply for hand torch

[M] - parts apply for machine torch

¹⁾ Torch connection fit to SPARTUS CUT machines (M16 cap with 2/4 pin plug)²⁾ Torch connection fit to SPARTUS CUT machines (central connector)